



**DE - Montagevideo ansehen:**  
QR-Code scannen

**EN - Watch installation video:**  
Scan QR-Code

## DE - Montageanleitung

**ACHTUNG!** Scharfe Kanten! Montage mit Handschuhen empfohlen.

- 1 Einsetzen der Montagehilfe von oben in die Dehnungsfuge (5 - 15 mm) zwischen Boden und Wand.
- 2 Einsetzen der Montageclips: Paralleles Eindrücken beider Federarme Richtung Wand.
- 3 Entfernen der Montagehilfe: Montageclip halten und Montagehilfe nach oben abziehen.
- 4 Schritte 1 - 3 ca. alle 40 - 60 cm wiederholen. Gegebenenfalls Kabel verlegen.
- 5 Sockelleiste von oben aufstecken. **WICHTIG:** Probeweises Positionieren der Sockelleiste vor Clip-Montage!

## EN - Assembly Instructions

**ATTENTION!** Sharp edges! Assembly with gloves recommended.

- 1 Insert the assembly aid from the top into the expansion joint (5 - 15 mm) between the floor and the wall.
- 2 Inserting the mounting clips: Push both spring arms parallel towards the wall.
- 3 Removing the mounting aid: Hold the mounting clip and pull the mounting aid upwards.
- 4 Repeat steps 1 - 3 approximately every 40 - 60 cm. Where applicable lay cable.
- 5 Mount skirting board from above. **IMPORTANT:** Check position of the skirting board before clip-mounting!