

- (D)** Montageanleitung
- (GB)** Assembly instructions
- (NL)** Handleiding voor de montage
- (PL)** Instrukcja montażu
- (HU)** Szerelési útmutató
- (RO)** Instrucțiuni de montaj
- (FR)** Notice de montage
- (IT)** Istruzioni di montaggio
- (CZ)** Montážní návod
- (SK)** Návod na montáž
- (TR)** Montaj talimatı
- (RU)** Инструкция по монтажу






**Service • Assistenza • Dienstverlening • Servis
Servis • Szerviz • Сервисная служба**

Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Nev Denimure • İsim • Название	MZ	
Nr • No • N° • Номер • C • Sz Typ • Type • Tip • Tipus • Tipo Tín	4.0146	

- | | | |
|-----|------------------|---|
| 1. | ASL 400x370x15mm | 1 |
| 1a. | ASR 400x370x15mm | 1 |
| 2. | ZB 718x718x15mm | 2 |
| 3. | ST 400x400x15mm | 1 |
| 4. | TR 396x513x15mm | 1 |
| 5. | RWL 399x360x3mm | 1 |
| 6. | RWR 399x730x3mm | 1 |


A8		2x	s		1x
B1		2x	s6		5x
l		12x	t		4x
l1		12x	v		1x
			z		20x



A8		2x
B1		2x
s6		2x
t		4x
v		1x


1

l		8x
l1		8x




3

l		4x
l1		4x




5

s6		4x27	3x
----	--	------	----




2

s		4x13	1x
---	--	------	----



4

z		20x
---	--	-----



6

